



# 零件表 PARTS LIST

N0.	零件名稱	Description	Q'ty	N0.	零件名稱	Description	Q'ty	N0.	零件名稱	Description	Q'ty
1	曲軸箱	crankcase	1	40	汽缸	cylinder	1	104	壓力表	pressure gauge	1
2	防塵蓋	dust-proof cap	1			brass	1	105	空氣室	air chamber	1
3	皮帶輪	pulley	1			cast iron	1	106	O形環	o-ring	1
4	固定螺絲	set bolt	1	41	螺絲附墊圈	screw, washer	4	150	安全弁組	safety valve assembly	1
5	固定螺絲	set bolt	6	42	雙頭螺絲	double-end screw	2	151	迴水座	overflow chamber	1
6	曲軸油封蓋	crankshaft oil seal cover	1	43	螺帽, 墊圈	nut, gasket	2			brass	1
7	加油蓋組	oil inlet cover assembly	1			grease	3			cast iron	1
8	後蓋迫緊	rear cover packing	1	44	黃油杯	cup	3	152	壓力閥	pressure valve	1
9	曲軸箱後蓋	rear cover	1	45	V迫緊底座	v-packing seat	6	153	壓力閥座	valve seat	1
10	固定螺絲	set bolt	4			UCL	6	154	方形環	gasket	1
11	油鏡組	oil window assembly	1	46	V迫緊	v-packing	6	155	螺絲附墊圈	screw, washer	2
12	排油螺絲組	drainage screw	1			F.P.M	6	156	調壓把手	pressure regulating handle	1
13	曲軸鍵	crankshaft key	1			F.P.M(Fabric)	6	157	固定螺絲	set screw	2
14	曲軸	crankshaft	1			NBR	6	158	伸縮套皮	packing	1
15	連桿組	connecting rod assembly	3			A120	6			F.P.M	1
16	軸承	bearing	2	47	黃油環	grease ring	3			NBR	1
17	曲軸油封	crankshaft oil seal	2	48	V型油環	v-type o-ring	3	159	保挂環	maintaining ring	1
18	曲軸油封蓋	crankshaft oil seal cover	1	49	調整環	adjusting ring	3	160	壓力閥杆	valve rod	1
19	柱塞組	piston assembly	3	50	固定夾	set clip	3	161	彈簧下座組	spring seat	1
20	柱塞桿	piston rod	3	51	進水室	suction chamber	1	162	調壓彈簧	pressure regulating spring	1
21	柱塞套	ceramic piston sleeve	3	52	進水口套	suction chamber cap	1	163	彈簧上座	spring seat	1
22	雙頭螺絲	double-end screw	3	53	螺絲附墊圈	screw, washer	2	164	螺絲附墊圈	screw, washer	2
23	O形環	o-ring	3	54	活門組	valve assembly	6	165	調壓彈簧座	pressure regulating pipe	1
24	墊圈	gasket	3	55	活門帽	valve cap	6	166	調壓螺絲組	pressure regulating screw	1
25	固定螺帽	set bolt	3	56	活門彈簧	valve spring	6	180	過濾網	filter	1
26	柱塞銷	piston pin	3	57	活門塞	valve plug	6	181	過濾網申日	socket	1
27	柱塞	piston[s.s]	3	58	活門座	valve seat	6	182	吸水管	suction hose	1
28	腳座	crankcase stand	2	59	活門皮	valve packing	6	183	吸水管蝶頭	suction hose wing nut	1
29	螺絲附墊圈	screw, washer	4	70	螺絲包	screw kit	1	184	吸水管申日	suction hose socket	1
30	固定銷	set pin	2	71	調整環扳手	adjusting-ring spanner	1			brass	1
31	柱塞油封	piston oil seal	3	72	十字起子	cross-Screw driver	1			general	1
32	柱塞防水圈	waterproof ring	3	73	開口扳手	open spanner	1	185	迴水管	overflow hose	1
				100	出水室	outlet chamber	1	186	迴水管蝶頭	overflow hose wing nut	1
				101	球形閥	ball cock	2	187	迴水管申日	overflow socket	1
										brass	1
										general	1