



PARTS LIST

1. BC4321H-RS MAIN BODY




Ref.No.	Part No.
1-1	363967
1-2	234162
1-3	234143
1-4	140474
1-5	012380
1-6	217045
1-7	217046
1-8	217047
1-9	092033
1-10	227728
1-11	217134
1-12	211203
1-13	217897
1-14	217900
1-15	231887
1-16	261762
1-17	231888
1-18	217138
1-19	217134
1-20	233626
1-21	223188
1-22	228207
1-23	228398
1-24	228399
1-25	226512
1-26	229762
1-27	228401
1-28	229763
1-29	232092
1-30	231262
1-31	237364
1-32	221580
1-33	232093
1-34	231704
1-35	223179
1-36	220632
1-37	231882
1-38	230747
1-39	261250
1-40	228325
1-41	230748
1-42	219113
1-43	219161
1-44	228086

2. BC4321H-RS
GEARCASE



Ref.No.	Part No.
2-1	234835
2-2	232833
2-3	234109
2-4	217134
2-5	234349
2-6	014490
2-7	106933
2-8	014210
2-9	054676
2-10	014490
2-11	012544
2-12	012380
2-13	232049
2-14	232322
2-15	232052
2-16	230849
2-17	232920
2-18	217135

3. BC4321H-RS ENGINE



Ref.No.	Part No.
3-1	858989
3-2	279099
3-3	279101
3-4	261246
3-5	285778
3-6	285779
3-7	265924
3-8	285781
3-9	285783
3-10	285784
3-11	266713
3-12	283315
3-13	286891
3-14	285786
3-15	285843
3-16	286362
3-17	288200
3-18	262658
3-19	262660
3-20	262565
3-21	012380
3-22	261612
3-23	285795
3-24	262476
3-25	262749
3-26	262659
3-27	262479
3-28	285797
3-29	282743
3-30	282624
3-31	263617
3-32	283671
3-33	262683
3-34	262682
3-35	282285
3-36	261250
3-37	287597
3-38	286207
3-39	287598
3-40	261076
3-41	262731
3-42	280381
3-43	287714
3-44	261256
3-45	288264
3-46	286988
3-47	283735
3-48	284541
3-49	264588
3-50	285809
3-51	285810

Ref.No.	Part No.
3-67	285736
3-68	285735
3-69	246301
3-70	265694
3-71	246302


Ref.No.	Part No.
3-62	285680
3-63	285681
3-64	285682
3-65	262638
3-66	268940

Ref.No.	Part No.
3-57	286296
3-58	286297
3-59	262633
3-60	262981
3-61	285679

Ref.No.	Part No.
3-52	286291
3-53	286292
3-54	286293
3-55	280995
3-56	286295

Ref.No.	Part No.
3-46	286988
3-47	283735
3-48	284541
3-49	264588
3-50	285809
3-51	285810









4. BC4321H-RS
CARBURETOR, FUEL TANK



Ref.No.	Part No.
4-1	287021
4-2	283124
4-3	263726
4-4	283905
4-5	263727
4-6	262994
4-7	282576
4-8	287061
4-9	261871
4-10	261875
4-11	264677
4-12	261876
4-13	264678
4-14	261658
4-15	261657
4-16	263737
4-17	282299
4-18	282512
4-19	282301
4-20	282302
4-21	282303
4-22	282484
4-23	282304
4-24	282305
4-25	269032
4-26	269423
4-27	261814
4-28	264807
4-29	282481
4-30	282306
4-31	285814
4-32	279350
4-33	286893
4-34	286067
4-35	275306
4-36	274875
4-37	286794
4-38	268065
4-39	261117
4-40	262649
4-41	261590
4-42	261117
4-43	267328
4-44	285735
4-45	261117

Ref.No.	Part No.
4-46	285819
4-47	281714
4-48	269032

5. BC4321H-RS
ACCESSORIES



Ref.No.	Part No.
5-1	228008
5-2	054756
5-3	212300
5-4	219432
5-5	219433
5-6	220534
5-7	227910
5-8	234901
5-9	241580
5-10	241581
5-11	241582
5-12	523304

