



PARTS LIST

1. BC5022H-RS PARTS KIT


Ref.No.	Part No.
1-1	246925
1-2	246926
1-3	246912
1-4	246927
1-5	246918
1-6	246915




1



2




3




4

5



6


2. BC5022H-RS
MAIN BODY



Ref.No.	Part No.
2-1	365113
2-2	234162
2-3	234143
2-4	140474
2-5	012380
2-6	217045
2-7	217046
2-8	217047
2-9	092033
2-10	227728
2-11	217134
2-12	211203
2-13	217897
2-14	217900
2-15	232696
2-16	232700
2-17	126993
2-18	244089
2-19	127216
2-20	231913
2-21	231914
2-22	244147
2-23	244148
2-24	244091
2-25	244092
2-26	217134
2-27	244241
2-28	223188
2-29	225379
2-30	243344
2-31	244229
2-32	244230
2-33	237241
2-34	243417
2-35	243418
2-36	234345
2-37	232092
2-38	231262
2-39	237364
2-40	221580
2-41	232093
2-42	223179
2-43	220632
2-44	231704
2-45	231882


Ref.No.	Part No.
2-46	230747
2-47	261250
2-48	228325
2-49	230748
2-50	219161
2-51	219113

3. BC5022H-RS GEARCASE



Ref.No.	Part No.
3-1	234835
3-2	232833
3-3	234109
3-4	217134
3-5	234349
3-6	014490
3-7	106933
3-8	014210
3-9	054676
3-10	014490
3-11	012544
3-12	012380
3-13	232049
3-14	232322
3-15	232052
3-16	230849
3-17	232920
3-18	217135

4. BC5022H-RS ENGINE



Ref.No.	Part No.
4-1	875709
4-2	288125
4-3	288171
4-4	261246
4-5	285778
4-6	285779
4-7	265924
4-8	288276
4-9	285783
4-10	285784
4-11	266713
4-12	283315
4-13	286891
4-14	285786
4-15	285843
4-16	286362
4-17	288200
4-18	262658
4-19	246472
4-20	246471
4-21	012380
4-22	261612
4-23	246091
4-24	282941
4-25	262749
4-26	262659
4-27	262479
4-28	285797
4-29	286905
4-30	246377
4-31	262683
4-32	262682
4-33	282285
4-34	261250
4-35	246097
4-36	246074
4-37	279547
4-38	261076
4-39	262731
4-40	280381
4-41	261256
4-42	288264
4-43	286988
4-44	283735
4-45	284541

Ref.No.	Part No.
4-65	248685
4-66	265694
4-67	246302
4-68	285735


Ref.No.	Part No.
4-61	280834
4-62	286922
4-63	261999
4-64	126990

Ref.No.	Part No.
4-56	281002
4-57	281004
4-58	262633
4-59	262981
4-60	281005

Ref.No.	Part No.
4-51	280997
4-52	555277
4-53	280999
4-54	281000
4-55	281001













Ref.No.	Part No.
4-46	264588
4-47	286919
4-48	280994
4-49	280995
4-50	280996

5. BC5022H-RS
CARBURETOR, FUEL TANK



Ref.No.	Part No.
5-1	289479
5-2	283124
5-3	263726
5-4	283905
5-5	263727
5-6	262994
5-7	282576
5-8	246486
5-9	261871
5-10	261875
5-11	264677
5-12	261876
5-13	264678
5-14	261658
5-15	261657
5-16	263737
5-17	282299
5-18	282512
5-19	282301
5-20	249203
5-21	261814
5-22	264807
5-23	282306
5-24	285814
5-25	279350
5-26	286893
5-27	286067
5-28	275306
5-29	274875
5-30	286794
5-31	268065
5-32	262649
5-33	261590
5-34	261117
5-35	247107
5-36	261117
5-37	261117
5-38	285819
5-39	285735
5-40	281714

6. BC5022H-RS
ACCESSORIES



Ref.No.	Part No.
6-1	228008
6-2	054756
6-3	219432
6-4	219433
6-5	220534
6-6	227910
6-7	234901
6-8	244232
6-9	244233
6-10	244234
6-11	244235
6-12	525396